


1
Hold stylus with rubber tip pointing up




2
Twist top half counter clockwise




3
Remove top and batteries



4
There should be 3 batteries and a plastic seal



5
Reinsert batteries without seal



6
Insert batteries with positive side is facing the rubber tip