



EAT21PN PARALLEL AUTOSWITCH

2 PCs SHARE 1 PARALLEL PRINTER

SETUP GUIDE

FEATURES:

- 2 PCs share 1 printer
- Automatically selects PC on first-come, first-serve basis
- LEDs indicate channel in-use
- DB25F connector parallel interface
- Power free, no adaptor required
- Includes mounting tape
- One year warranty

Note: Power is provided to the autoswitch from printer through the printer cable. Please use 25 wire instead of 18 wire type printer cable for best results.

INSTALLATION INSTRUCTIONS:

1. Connect PC's to input ports A and B with 25 wire straight thru DB25M/M cables
2. Connect switch port C to printer with parallel printer cable
3. No setting, no adjustments; just connect and use!
4. Tool-free installation

RECOMMENDED QVS CABLES:



PC Port	Cable	Switch	Cable	Device
DB25F Parallel	CC305	EAT21PN	CC304	Parallel Printer

PACKAGE CONTENTS:

- Switch assembly
- Double sided mounting tape
- These instructions and a warranty card

INSTALLATION DIAGRAM

2 COMPUTERS SHARING 1 PRINTER




PERFORMANCE TIP!

Enhance your system performance with a QuickByte hi-speed buffer.

FEATURES:

- Superfast data rates (30-65KCs) break the printer speed bottleneck with fast CPUs (Pentium/486)
- Data compression up to 70% increases RAM
- Plug into parallel printer port (Cen36F/M) or use as a booster to extend printer distance to 70ft
- Cascadable for easy memory expansion
- Includes 9vDC 100mA power Adaptor



PART NUMBER	BUFFER SIZE
FB190	256K
FB190-1M	1MEG
FB190-2M	2MEG
FB290-4M	4MEG

Available from your dealer!