

DIGITAL COAX RCA TO S/PDIF TOSLINK OPTICAL AUDIO CONVERTER

(SKU: FCTK-RCA-R | REV1) MANUAL V1

Setup Guide:

This audio converter converts digital coaxial RCA to S/PDIF Toslink digital optical. It allows the use of audio sources from CD/DVD/Blu-ray players to be used on A/V receivers with Toslink inputs. The S/PDIF output supports PCM, Dolby and DTS multi-channel audio. It offers a solution for home theater system, conference room, sound room, school and corporate training environment.

- a) Connect RCA cable between digital coax output on source to converter coax input.
- b) Connect Toslink cable between converter Toslink output to receiver/sound bar.
- c) Connect included power adaptor to AC outlet and converter.
- d) Turn-on source and receiver/sound bar.

Note: If you need to convert Toslink optical into RCA digital coax, use FCTK-RCA. **This does not convert ANALOG RCA stereo audio into S/PDIF Toslink.**

If you have any question or need any help with this cable, please go to
<http://www.shopqvs.com/support>

You can also call us at (702) 228-3670 Monday to Friday,
from 9:00am - 5:00pm PST or email us at support@qvs.com.

VISIT US ON THE WEB @

WWW.QVS.COM