



Hold stylus with rubber tip pointing up




Twist top half counter clockwise




Remove top and batteries



There should be 3 batteries and a plastic seal



Reinsert batteries without seal



Insert batteries with positive sides facing the rubber tip