

USB 2.0 ACTIVE EXT. CABLE

BUILT-IN 16FT CABLE, EXTENDS UP TO 80FT

(SKU: USB2-RPTRMC)

Application Guide:

- a) Before using the USB repeater, install the software driver required for the USB device including printer, scanner, video cam, etc. by connecting it directly to the computer. Once installed and tested, un-plug the device.
- b) Connect the USB repeater into computer's USB port and let it installed the required software. The software is built-in into computer's operating system.
- c) Connect the USB device into USB repeater.

Up to 5 repeaters can be connected to extend USB reach up to 80ft. When used with USB bus-powered devices (these are USB peripherals without their own power supply) and the repeater can't supply the required power, connect a USB powered-hub at the end of the repeater. If you have any question or need any help with this cable, please go to

<http://www.qvs.com/support/supportform.asp>

You can also call us at (702) 228-3670 Monday to Friday, from 9:00am - 5:00pm PST or email us at support@qvs.com.

VISIT US ON THE WEB @

WWW.QVS.COM